

# PARTS LIST

## XLERATOR® Models

Ref. #	Stock #	Description – Refer to diagram on reverse side
XL 1	XL-1064	Cover - White (includes Nameplate)
	XL-1065	Cover - Chrome (includes Nameplate)
	XL-1066	Cover – Graphite (includes Nameplate)
	XL-1067	Cover - BMC (includes Nameplate)
	XL-1068	Cover – Stainless (includes Nameplate)
XL 2	XL-60	Nameplate <b>XLERATOR®</b>
	XL-61	Nameplate <b>XLERATOR®</b> - Without Excel Dryer
XL 3	XL-626	Tamper proof Bolt
XL 4	XL-630	Tamper proof Wrench
XL 5	XL-62	Air Outlet Assembly – Nozzle (includes gasket #34 & screws )
	XL-62.2	Air Outlet Assembly – Nozzle 1.1 diameter (includes gasket #34 & screws )
XL 6	XL-40040	Terminal Block with Screws and Tabs
XL 7	XL-40100	Control Assembly & Sensor 110/120V (includes XL15 and mounting bracket )
	XL-40101	Control Assembly & Sensor 208/277V (includes XL15 and mounting bracket )
XL 8	XL-40000	Heating Element Assembly 110/120V (includes gasket and screws)
	XL-40001	Heating Element Assembly 220/240V (includes gasket and screws)
	XL-40002	Heating Element Assembly 208V (includes gasket and screws)
XL 9	XL-40300	Motor Assembly 120V (includes gaskets & wire harness)
	XL-40301	Motor Assembly 208/240V and 277V (includes gaskets & wire harness)
	XL-295	Motor Brush 110V – Each (including sleeve)
	XL-296	Motor Brush 220V – Each (including sleeve)
XL 10	XL-40400	Wall Plate Assembly (includes cover mounting brackets)
XL 11	XL-12	Cover Mounting Brackets - Set of 2
XL 12	XL-36	Housing Grommet (rubber) – Set of 4
XL 13	XL-14	Housing Retainer – Set of 4 (includes screws)
XL 14	XL-40501	Recess Kit (for ADA compliance) – No Discount
XL 15	XL-30083	Optics only (sensor) for Control Assembly
	XL-40200	Blower/Motor Complete 110/120V (includes all except wall plate/cover)
	XL-40201	Blower/Motor Complete 208V (includes all except wall plate/cover)
	XL-40202	Blower/Motor Complete 220/240V (includes all except wall plate/cover)
	XL-26	Air Inlet Cover (includes screws)
	XL-29.6	Fuse (110V only – early versions) 6.25 Amp
	XL-29.8	Fuse Holder (110V only – early versions only)
	XL-1400	XL 110V Sub Assembly on Wall Plate – <b>1400L</b> for 1.1 Nozzle
	XL-1401	XL 220/240V Sub Assembly on Wall Plate – <b>1401L</b> for 1.1 Nozzle
	XL-1402	XL 208V Sub Assembly on Wall Plate – <b>1402L</b> for 1.1 Nozzle

**XLERATOR® Hand Dryer Parts Diagram**

